

## Apple IIGS: Printing to the LaserWriter from AppleWriter

Revised: 7/2/87 Security: Everyone

Apple IIGS: Printing to the LaserWriter from AppleWriter

\_\_\_\_\_\_

Applewriter II works correctly on the Apple IIGS, except that you cannot print using the built-in ports to a standard RS-232 serial printer. You can, however, use the ports to print to a Laserwriter or an Imagewriter II over Appletalk. You can also print to either a parallel or serial printer by simply installing a compatible interface card, such as a Super Serial or Parallel card, into one of the Apple IIGS's slots.

To print to the Laserwriter or an Imagewriter II over Appletalk, you must first use the Chooser that comes with the Apple IIGS system disk. Choose the Appletalk printer that you would like to print your documents on, and then exit the program. When you are in Applewriter II, make sure that the last line of your document contains a form feed command. To do this, just type in the following as the last line in your document:

Control-V Control-L Control-V

This command will force the Appletalk Imagewriter and Laserwriter to eject the last page of the document.

For a deeper discussion on how to print to the LaserWriter from the GS, albeit with AppleWorks, see the article in this Library called "Apple IIGS: Printing to the LaserWriter from AppleWorks."

Tech Info Library Article Number:2258