



Tech Info Library

New Ground Wire to HyperDrive Bracket

Revised: 1/7/87
Security: Everyone

New Ground Wire to HyperDrive Bracket

=====

The current DC power supply harness of the HyperDrive 20 has a green ground wire on the line to the hard disk assembly. This green wire should be attached to the small spade on the silver DRIVE BRACKET surrounding the drive and not to any spade you might see on the drive itself. If there is no spade on the bracket, the ground wire should be snipped off.

NOTE: Apple Computer, Inc. is not responsible for the contents of this article.

General Computer Co., Service Documentation

Tech Info Library Article Number:2111