



Tech Info Library

Epson FX-80 printer: Using it with a IIC

Revised: 7/9/85
Security: Everyone

Epson FX-80 printer: Using it with a IIC

=====
Most Epson FX-80 printers are built to operate with parallel computers. In order for them to work with the Apple IIC, the Epson Intelligent Serial Interface Card must be installed in the printer. The default setting for baud rate on this card, however--19200 BPS--needs to be changed to 9600 BPS in order for the printer to communicate with the IIC.

Set the following switches on the SIC as shown below in order to change the card's baud rate to 9600 BPS:

- SW1-5 = OFF
- SW1-6 = ON
- SW1-7 = OFF
- SW1-8 = OFF

Apple Technical Communications

Tech Info Library Article Number:1176