

MacTest 6.0: Wrong Error Number During Test Of External Drive

Revised: 11/9/88 Security: Everyone

MacTest 6.0: Wrong Error Number During Test Of External Drive

This article last reviewed: 9 November 1988

MacTest 6.0 displays an erroneous error number during the external drive test when it's run for the first time. You can perform a valid test without rebooting simply by running the external drive test a second time.

Follow these steps when you want to use MacTest 6.0:

- 1. Boot MacTest 6.0 on either a 512K or 128K Macintosh. Run all tests by choosing Start.
- 2. If all is well, Pass will be highlighted. Choose Select Test, then specify that only the external drive test be run.
- 3. Click on Start. MacTest will return a Failed message with the number 50010.0004.
- 4. Click on Start again. This time the drive test should run properly. If the external drive is good, the test will indicate "Pass"; if the test returns a "Failed" message again, the drive is indeed faulty.

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:1277