



# Tech Info Library

## Manzanita software: Printer Switch Settings

Revised: 3/10/86  
Security: Everyone

Manzanita software: Printer Switch Settings

=====  
The Business Accountant, The Advanced Business Accountant, and BusinessWorks require 10 characters per inch to properly align on preprinted forms.

Imagewriter:

	8	7	6	5	4	3	2	1	
Switch 1:				X					Closed
	X	X	X		X	X	X	X	Open

	4	3	2	1	
Switch 2:			X	X	Closed
	X	X			Open

Refer to page 40 and 41 of the Imagewriter Manual.

Imagewriter II:

Switch settings same as for Imagewriter. Be sure the perforation skip switch is off.

Interface Cards:

Grapler Plus: Must be version 3.2. To test for version, boot computer and enter PR#1 (be sure the printer is on and on-line). With the caps lock key on, enter Control-I V. The version of the card will print to the printer. Enter Control-I 80N for special character string in "Change Line Printer Configuration" option of System Setup and Configuration Menu.

NOTE: Apple Computer Inc. is not responsible for the contents of this article.

Tech Info Library Article Number:1796