



# Tech Info Library

## LaserWriter IIntx: What The ROM/Font Expansion Card Is For

Revised: 1/21/88  
Security: Everyone

LaserWriter IIntx: What The ROM/Font Expansion Card Is For

=====

This article last reviewed: 15 January 1988

The purpose of the LaserWriter IIntx Font Expansion Card is to provide additional ROM storage for fonts. The fonts must be stored either as character bitmaps or as character outlines. Refer to the PostScript Language Reference Manual for the character outline definitions and contact Adobe Systems for information about conforming to the Adobe cartridge-font definition.

The Font Expansion Card, 5.25 x 4.6 inches, interfaces with the controller ROM through a 96-pin DIN connector.

For more information about cartridge-font definition, search under: Adobe Systems Inc.

Tech Info Library Article Number:2035