



Tech Info Library

FullPaint and the Hyperdrive

Revised: 2/10/87
Security: Everyone

FullPaint and the Hyperdrive

=====

FullPaint requires 384K just to launch. If the HyperDrive Volume Manager is not configured properly, the program will not load and will tell the user that he needs to check RAM Cache.

Following is the procedure for getting FullPaint to run on non-XP HyperDrives:

'Preferences' must be set to 'Maximum Compatibility'

OPEN Volume Manager

Choose PREFERENCES from the CREATE menu

Set the buttons to Maximum Compatibility

Close the PREFERENCES window

QUIT the Volume Manager

Choose SHUTDOWN from the Special menu

NOTE: Apple Computer, Inc. is not responsible for the contents of this article.

Ann Arbor Technical Support

Tech Info Library Article Number:2133