



Tech Info Library

FullPaint and MacServe

Revised: 2/20/87
Security: Everyone

FullPaint and MacServe

=====

2/6/87

Following is a description of how to get FullPaint to run on a MacServe network.

RAM Caching must be set to 'Minimum' (10K) in the MacServe Manager

Open MacServe Manager

Choose STARTUP OPTIONS from the Settings menu

Set RAM caching to 10K (minimum)

Click the SET button

QUIT the MacServe Manager

Choose SHUTDOWN from the Special menu

512K Macintosh as the network server

FullPaint will NOT work under any circumstances on a 512K Mac that is being used as the server for the network. 512K net users may use FullPaint. MacServe software uses about 130K and FullPaint requires 384K just to launch.

For further information contact Ann Arbor technical support.
Our AppleLink address: D0294.
Our tech support phone lines: (805) 375-1491.

NOTE: Apple Computer, Inc. is not responsible for the contents of this article.

Ann Arbor Technical Support

Tech Info Library Article Number:2149