



Tech Info Library

LaserWriter: How To Print On Legal-Size Paper Without A Cassette

Revised: 12/3/88
Security: Everyone

LaserWriter: How To Print On Legal-Size Paper Without A Cassette

=====

This article last reviewed: 21 October 1988

It's possible to print on legal-size paper even if you have no legal paper input cassette. (If a letter-size paper cassette is installed, the LaserWriter or LaserWriter II assumes it's printing on letter-size paper.) This procedure assumes your application uses the standard Apple Page Setup dialog.

1. Choose Page Setup from the File menu. Select the US Legal button.
2. Click the Options button.
3. Click the box next to Larger Print Area. This shrinks the "nonprintable" area on the paper. (Without this step, the image is out of registration by 1/3 the length of the paper.)
4. Choose Print from the File menu.
5. Choose Manual Feed in the print dialog box.

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:2279