



# Tech Info Library

## AppleShare, LaserShare, InterMail: All From One Server

Revised: 11/2/88  
Security: Everyone

AppleShare, LaserShare, InterMail: All From One Server

=====

This article last reviewed: 1 September 1987

It is possible to use the same hard disk for AppleShare, LaserShare, and InterMail. One Macintosh Plus, Macintosh SE, or Macintosh II with server can then do triple duty: file, printer, and mail service.

1. Copy InterMail's server icon into the AppleShare server folder.

On first launch, loading before AppleShare, InterMail creates its own data file, which disrupts AppleShare's launch. We'll take of that in a moment.

2. Start up the Server Installer.

3. Drag the InterMail data file into the Server folder.

4. Run AppleShare's Admin application, which 'repairs' the server desktop.

5. Restart. InterMail and AppleShare will run properly.

6. While installing LaserShare according to the directions, enable it as a 'Concurrent Application.'

7. Restart again. All three applications will load and run.

Since InterMail loads first, and in the background, its memory is reserved before AppleShare and LaserShare launch.

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:2392