

LaserWriter IINT/NTX: Two Corrections to Owner's Guide

Revised: 5/2/88 Security: Everyone

LaserWriter IINT/NTX: Two Corrections to Owner's Guide

This article last reviewed: 19 April 1988

The "LaserWriter IINT/NTX Owner's Guide" (030-315-A), in the section titled "Using the 25-pin connector," fails to mention that a modem eliminator is needed. The complete connection is:

25-pin serial cable to 25-pin Apple Modem Eliminator (590-0166-A) to serial port on LaserWriter II

In the subsection "Making the connection," step 6, the MS-DOS commands should be:

MODE COM1:96,N,8,1,P MODE LPT1:=COM1:

With the commands in the manual, Shift-* doesn't print the screen as it's supposed to.

Tech Info Library Article Number: 2826