



# Tech Info Library

## Apple IIe: How To Connect To An AppleShare Network

Revised: 5/11/89  
Security: Everyone

Apple IIe: How To Connect To An AppleShare Network

=====

This article last reviewed: 1 November 1988

An unenhanced Apple IIe requires the Apple IIe Enhancement kit (consisting of new ROMs and CPU), the Apple Workstation card, and 128K RAM to be connected to an AppleShare network.

An enhanced Apple IIe requires only the Apple Workstation card and 128K RAM.

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:3434