Tech Info Library

Macintosh SE: Kodak Data Show's White Wire Connection

```
Revised:        3/4/90
Security:       Everyone
```

Macintosh SE: Kodak Data Show's White Wire Connection

===

This article last reviewed: 15 February 1990

TOPIC ---

I was upgrading the memory of a Macintosh SE that had a Kodak Data Show card installed. The clip on the white wire that connects the Kodak card to a chip on the Main Logic Board came off. I have two questions: which chip was it connected to and which pin on that chip?

DISCUSSION --

The white wire connects to the GLU chip at D9 pin #19. If you are looking at that chip laying horizontally with the notch on the left, #19 is the second pin from the left on the top row.

Copyright 1990 Apple Computer, Inc.

Tech Info Library Article Number:5177