



# Tech Info Library

## Personal LaserWriter NT Software Switching

Revised: 1/18/91  
Security: Everyone

Personal LaserWriter NT Software Switching

=====  
This article last reviewed: 28 November 1990

TOPIC -----

Is it possible to soft switch the Personal LaserWriter NT between PostScript and HP Emulation? The PostScript code for the LaserWriter IINTX doesn't seem to work.

DISCUSSION -----

You are correct, the PostScript code for the LaserWriter IINTX for software mode switching does not work on the Personal LaserWriter NT. The "setsoftwareiomode" value, which is used in the LaserWriter IINTX to set the mode, is not defined in the Personal LaserWriter NT.

However, you can use software switching to switch the Personal LaserWriter NT temporarily from PostScript to HP LaserJet+ or Diablo emulation. To emulate the HP LaserJet+, send the following PostScript to the Personal LaserWriter NT:

```
statusdict begin
currentfile /hpcl emulate
```

To emulate the Diablo, send the following PostScript to the Personal LaserWriter NT:

```
statusdict begin
currentfile /Diablo emulate
```

This DOES NOT work the same way software switching to set the mode on a LaserWriter IINTX works. As soon as this job is completed, the Personal LaserWriter NT will change back to PostScript mode. Therefore, you must send this code at the beginning of each job with the job appended to it. To do this, you could put the previous PostScript code in a file, say "hpcl.ps". Then, to print a job in HP LaserJet+ mode from a PC, type:

```
copy hpcl.ps+filename.txt lpt
```

This would send the file you want printed in the same job as the PostScript code that switches the Personal LaserWriter NT to HP LaserJet+ mode. If these files are sent separately, the Personal LaserWriter NT will have already reset back to PostScript mode before the file to be printed reaches the printer.

As this PostScript must be sent with every job, a file cannot be printed straight from a program to the Personal LaserWriter NT. The file would have to be saved to disk, and then sent to the Personal LaserWriter NT as specified above.

You can also set the pushwheel switch on the Personal LaserWriter NT for HP LaserJet+ or Diablo emulation. Switch position 2 sets it to HP LaserJet+ mode, and switch position 3 sets it to Diablo mode.

Copyright 1990 Apple Computer, Inc.

Tech Info Library Article Number:6438