

Macintosh LC: Screen Print to an ImageWriter

Revised: 7/23/92 Security: Everyone

Macintosh LC: Screen Print to an ImageWriter

Article Created: 15 May 1991

Article Last Reviewed: 23 July 1992

Article Last Updated:

TOPIC -----

When using the Command-Shift-4 key sequence to print the screen, the ImageWriter defaults to the modem port. If you open the Chooser, reselect the printer port, and then close the Chooser, the ImageWriter still defaults to the modem port. Can you get a screen print on a Macintosh LC connected to an ImageWriter?

DISCUSSION -----

You can get a screen print with a Macintosh LC when you leave the Chooser window open as the top window, and print to the ImageWriter using Command-Shift-4.

A better solution is to use the Command-Shift-3 key sequence to print the screen to a disk file. Then open the disk file in MacPaint, and print from there.

Copyright 1991, Apple Computer, Inc.

Tech Info Library Article Number: 7436