

## ImageWriter II: Switch Settings for Use with a Apple IIe

Revi	sed	:	7/2/91	
Secu	rit	y:	Everyone	
Imag	eWr:	iter II	I: Switch Settings for Use with a Apple IIe	
====	===:	======		====
This	ar	ticle l	last reviewed: 15 July 1990	
TOPI	C -			
What	ar	e the p	proper settings for using an Apple IIe with a Super	
Seri	al (	Card to	o an ImageWriter II?	
DISC	USS:	ION		
_				
The	set <sup>·</sup>	tings s	should be:	
Curo	<b>-</b> ~ C.	erial (	Tand	
_		off	Laiu	
SWI		off		
		off		
		on		
		off		
	6	on		
	7	on		
SW2	1	on		
	2	off		
	3	off		
	4	off		
	5	on		
		off		
	7	off		
Jump	or	block	pointed toward terminal.	
ս աուբ	CI	DIOCK	pointed toward terminar.	
Imaq	eWr	iter II	I	
sw1	1	off		
	2	off		
	3	off		
	4	off		

## $.. TIL 07737-Image Writer\_II-Switch\_Settings\_for\_Use\_with\_a\_Apple\_IIe\_(TA46368).pdf$

```
5 off
```

SW2 1 on

\_ \_\_\_\_\_

2 on

3 off

4 off

Cable: 590-0335 or 590-0556

Copyright 1991, Apple Computer, Inc.

Tech Info Library Article Number:7737

<sup>6</sup> on