



Tech Info Library

Lisa: Error 38 is No Boot File on Disk

Revised: 9/5/91
Security: Everyone

Lisa: Error 38 is "No Boot File on Disk"

=====

Article Created: 14 May 1991
Article Last Reviewed: 27 May 1991
Article Last Updated:

TOPIC -----

When I try to boot a MacWorks disk on my Lisa, I get an error code 38.

This error is placed under an icon with a check in it. It only accesses the floppy for a brief moment and then gives the error code. It then prompts me to continue or to choose a startup device (STARTUP FROM...). When I continue, the above occurs again, over and over. If I choose a startup device, it gives me the option of the floppy only -- not the HD.

What's going on?

DISCUSSION -----

Error 38 is "No Boot File on Disk." It sounds like the MacWorks disk was erased. If the disk was good to begin with, you have a hardware problem with the floppy drive.

Copyright 1991, Apple Computer, Inc.

Tech Info Library Article Number:8153