



Tech Info Library

ImageWriter I: Troubleshooting with Macintosh Classic (2/96)

Revised: 2/5/96
Security: Everyone

ImageWriter I: Troubleshooting with Macintosh Classic (2/96)

=====
Article Created: 13 August 1991
Article Reviewed/Updated: 5 February 1996

TOPIC -----

I cannot get my Macintosh Classic to work with my ImageWriter I.

DISCUSSION -----

Step 1

Make sure that the ImageWriter I printer's switch settings are correct:

Switch 1

- 1-Off
- 2-Off
- 3-Off
- 4-Off
- 5-Off
- 6-On
- 7-Off
- 8-Off

Switch 2

- 1-ON
- 2-ON
- 3-OFF
- 4-XX

Step 2

Verify that you are using the correct cable. Cable part number 590-0555, or the original Macintosh to ImageWriter DB-9 to DB-25 cable (part # 590-0169) with the

DB-9 to Mini DIN 8 Macintosh Peripheral Adapter cable (part # 590-0553) can be used.

Step 3

From the Chooser, verify the following:

- ImageWriter driver is selected
- AppleTalk is off
- The correct port is selected

If this does not work, you may want to start looking for hardware failures: Try the ImageWriter on another computer, then try another printer with your computer.

Article Change History:

05 Feb 1996 - Added additional cable information.

Support Information Services

Copyright 1991-96, Apple Computer, Inc.

Tech Info Library Article Number:8674