

PowerBook: Using External Device to Discharge NiCad Battery 2/92

There should be no problems using an external discharge device to discharge and then recharge a the NiCad battery in a PowerBook 140, 145, 160, 170, or 180.

This should NOT be done, however, with a PowerBook 100 or PowerBook Duo, which do not have a NiCad battery.

Article Change History

11/2/92 - Updated for new models.

Support Information Services

Copyright 1992 Apple Computer, Inc.

Tech Info Library Article Number:9857