



Tech Info Library

PowerBook: Cause of Feedback When Attaching Microphone (11/92)

Revised: 5/18/94
Security: Everyone

PowerBook: Cause of Feedback When Attaching Microphone (11/92)

=====
Article Created: 27 October 1992

TOPIC -----

FaxSender doesn't turn off the sound port after sending a fax.

DISCUSSION -----

When you send a document using FaxSender and then plug the microphone into the microphone jack without restarting, it will produce feedback because the sound port is still open.

Support Information Services

Copyright 1992, Apple Computer, Inc.

Tech Info Library Article Number:10574