



# Tech Info Library

## LaserWriter: What Happens to a Document After a Paper Jam

Revised: 12/14/92  
Security: Everyone

LaserWriter: What Happens to a Document After a Paper Jam

=====

Article Created: 3 December 1992

TOPIC-----

What happens to the document being printed when a PostScript LaserWriter recovers from a paper jam?

DISCUSSION -----

LaserWriter, LaserWriter Plus, LaserWriter IINT/NTX, Personal LaserWriter NT

-----  
After a paper jam is cleared, these printers discard ("flush") the page that was being printed when the printer jammed, then print the rest of the document.

Original LaserWriter IIIf, LaserWriter IIg

-----  
The original LaserWriter IIIf and LaserWriter IIg print two blank pages after a paper jam is cleared. This serves two purposes:

- To clean excess toner from the paper path
- To verify that a jam condition does not still exist before trying to image another page.

Unlike the earlier LaserWriter printers, the LaserWriter IIIf and IIg re-print the page that was printing when the jam occurred.

Personal LaserWriter NTR, Upgraded LaserWriter IIIf and LaserWriter IIg

-----  
A LaserWriter IIIf or LaserWriter IIg that has had a ROM upgrade, and the Personal LaserWriter NTR, eject only one blank page before reprinting the remainder of the document. These printers also re-print the page

that was being printed when the paper jam occurred.

Copyright 1992, Apple Computer, Inc.

Tech Info Library Article Number:11060