



Tech Info Library

Portable StyleWriter: Attaching the Sheet Feeder (7/93)

Revised: 10/25/93
Security: Everyone

Portable StyleWriter: Attaching the Sheet Feeder (7/93)

=====
Article Created: 13 July 1993
Article Reviewed/Updated: 25 October 1993

TOPIC -----

This article discusses how to attach the Automatic Sheet Feeder to the Portable StyleWriter.

DISCUSSION -----

The Automatic Sheet Feeder (optional attachment) enhances the printer's capability to function as a desktop printer. The sheet feeder can hold up to 50 sheets of paper for automatic feeding to the printer.

The sheet feeder attaches to the back of the printer when the printer is in the vertical position.

To use the Auto Sheet Feeder, position dip switch 1 in the printer to the ON position (up). The dip switch is located under the paper cover on the right side.

Sheetfeeder Specifications:
Size: 12.2 x 8.6 x 2.3
Weight: 2.9 pounds
Bin Capacity: 50 sheets @ 17 pounds
Paper Sizes: Letter, Legal, A4, B5 envelopes
Paper Weight: 17 to 24 pounds

Article Change History:
25 October 1993 - Added sheetfeeder specifications

Tech Info Library Article Number:12598