



Tech Info Library

Portable StyleWriter: Manual Feed (7/93)

Revised: 7/13/93
Security: Everyone

Portable StyleWriter: Manual Feed (7/93)

=====
Article Created: 13 July 1993

TOPIC -----

This article discusses how to load envelopes or other material in the Portable StyleWriter.

DISCUSSION -----

You can load one envelope, transparency, or sheet of stock paper in the printer for a manual feed. The printer should be turned on, with the Power and Error lights lit.

- 1) Position the printer for vertical operation by rotating the footer on the back of the printer case.
- 2) Open the top cover.
- 2) Set the paper thickness adjustment dial in the correct position. The thumbwheel is located on the right bottom of the printer. For example: Set the dial to the envelope icon if you will be printing on an envelope.
- 3) Align/insert the envelope or sheet into the slot on the back of the printer.

NOTE: The printer prints on the side of the envelope or sheet that faces up.

- 4) Press the LF/FF button to feed the material into the printer. The Error light turns off.
- 5) Press the On Line button to make the printer ready for printing.

Copyright 1993, Apple Computer, Inc

Tech Info Library Article Number:12600