



Tech Info Library

Newton: How to Insert Storage/Application Cards (10/94)

Revised: 6/5/96
Security: Everyone

Newton: How to Insert Storage/Application Cards (10/94)

=====
Article Created: 30 July 1993
Article Reviewed/Updated: 24 October 1994

TOPIC -----

This article describes how to insert storage or application cards into your Newton.

DISCUSSION -----

Your Newton has a card slot which can accommodate a PCMCIA type II-standard card. This card can be either a storage card, which provides extra memory and user space or an application card, which provides software programs and more features.

Here's how to insert a storage or application card into your Newton:

- 1) Turn off your Newton.
- 2) Lift up the latch on the front left side of the Newton. Slide and release the lever underneath this latch.
- 3) Remove the currently installed card from the slot on the front of the Newton. If you have never put a card into your Newton, you will find a dummy plastic card which occupies the card slot. Keep this card and put it back in the card slot when you do not have a real card.
- 4) Insert your storage/application card with the arrow on top pointing toward your Newton. Push the card all the way in until you hear a click.
- 5) Push the latch back down. The storage/application card is now installed in your Newton.

NOTE: You should never use or store your Newton with an empty card slot. After you eject a card, be sure to insert a storage/application card or the protective

plastic card that came with your Newton.

Article Change History:

24 Oct 1994 - Reviewed for consistency and updated format.

Support Information Services

Copyright 1993-94, Apple Computer, Inc.

Tech Info Library Article Number:12764