



# Tech Info Library

## Newton: How to Insert/Replace Batteries (8/94)

Revised: 9/1/94  
Security: Everyone

Newton: How to Insert/Replace Batteries (8/94)

=====  
Article Created: 30 July 1993  
Article Reviewed/Updated: 31 August 1994

TOPIC -----

This article describes how to insert and/or replace the batteries into your Newton.

DISCUSSION -----

There are two different batteries in the Newton, the main battery pack and the backup battery. The main battery pack consists of either a battery holder which contains 4 disposable AAA batteries or a rechargeable nickel-cadmium battery pack. The backup battery is a round disposable 3-volt Duracell DL2032 lithium battery.

Warning: If both the main battery pack and the backup battery are exhausted, you will lose the entire contents of your Newton's memory, including any memory-based system updates that have been loaded into your Newton.

### Replacing the Main Battery Pack

-----

- 1) Place your Newton screen-side down on a surface that won't damage the screen.
- 2) Remove the rear battery cover. You will see a large rectangular opening for the main battery pack, a small round opening for the backup battery, an orange switch and a reset switch.
- 3) Slide the orange switch to the Replace Main position.
- 4) Insert a small coin in the slot on the left side of the main battery pack, then use the coin to lift the battery pack out of the battery compartment.

- 5) If you are using a disposable battery pack, open the door on the battery pack, remove any discharged AAA batteries, and insert fresh batteries. Be sure to orient the batteries as shown on the battery holder.
- 6) Slide the fresh battery pack into the Newton from left to right and press the battery pack down into place. Be sure not to damage the spring-style power terminals inside the battery compartment.
- 7) Move the orange switch to the In Use position.

Note: If you are installing batteries in your Newton for the first time ONLY, press the reset switch with the plastic stylus that is included with your Newton.

- 8) Replace the rear battery cover. You may now use your Newton.

#### Replacing the Backup Battery

- 
- 1) Place your Newton screen-side down on a surface that won't damage the screen.
  - 2) Remove the rear battery cover. You will see a large rectangular opening for the main battery pack, a small round opening for the backup battery, an orange switch and a reset switch.
  - 3) Slide the orange switch to the Replace Backup position.
  - 4) If a backup battery is already in place, remove it.
  - 5) Pick up the fresh backup battery by its edges and insert it into its opening. Wipe off any fingerprints with a soft cloth.

Warning: BE SURE to insert backup battery with the positive (+) side up. If the battery is inserted incorrectly, it may explode.

- 6) Move the orange switch to the In Use position and replace the rear battery cover. You may now use your Newton.

#### Article Change History:

31 Aug 1994 - Reviewed for accuracy.

#### Support Information Services

Copyright 1993-94, Apple Computer, Inc.

Tech Info Library Article Number:12765