

Newton MessagePad: Won't Turn On (7/93)

Revised:	7/29/93
Security:	Everyone
	Pad: Won't Turn On (7/93)
============	
Article Created	d: 30 July 1993
TOPIC	
I can't turn or	n my Newton MessagePad. What should I do?
DISCUSSION	
	first time you've tried to power on, try hitting the reset

- If it's the first time you've tried to power on, try hitting the reset button in the battery compartment on the back of the Newton. You should only have to do this once, and subsequent start-ups should be possible by pulling down the spring-loaded switch on the side of the Newton.
- If you have the power adapter plugged in and can't start up, make sure it's plugged into a working outlet. If it's plugged into a power strip, make sure the power strip is turned on.
- If you are using batteries, try a fresh set.
- Make sure the switch in the battery compartment is set to "In Use."

Copyright 1993, Apple Computer, Inc.

Tech Info Library Article Number:12813