



Tech Info Library

PowerShare: Minimum Server Requirements (9/93)

Revised: 9/28/93
Security: Everyone

PowerShare: Minimum Server Requirements (9/93)

=====
Article Created: 28 September 1993

TOPIC -----

This article describes the minimum system requirements for a PowerShare server.

DISCUSSION -----

You'll need the following hardware to set up a PowerShare Server system:

- At least one Macintosh computer (using a 68020 or later processor) with a hard disk.
- A minimum of 4 megabytes of memory for each installed server.
- If both the PowerShare catalog server and the PowerShare mail server are installed on the same computer you will require at least 8 MB.
- The PowerShare Server system requires system software version 7.1.1 or later.

Notes:

If this version of system software is not already installed on the Macintosh computers that will be running the server software, the Installer will automatically update the system software during installation.

The system can be administered from the same computer on which the servers are installed or from any other computer on the network on which the PowerTalk system software has been installed. The computer serving as the administration station can be any Macintosh computer with at least 5 megabytes of memory.

Copyright 1993, Apple Computer, Inc.

Tech Info Library Article Number:13478