



Tech Info Library

Newton Print Pack: Compatible Printers (A-L) (3/95)

Revised: 3/30/95
Security: Everyone

Newton Print Pack: Compatible Printers (A-L) (3/95)

Article Created: 1 August 1994
Article Reviewed/Updated: 30 March 1995

TOPIC -----

Listed below are printers that will print to a Newton MessagePad when used with the Newton Print Pack.

DISCUSSION -----

AEG Olympia

Manufacturer	Model	Driver
-----	-----	-----
AEG Olympia	Laserstar 6e	LJ II
AEG Olympia	NP 30	FX
AEG Olympia	NP 60	FX
AEG Olympia	NP 80 SE	FX
AEG Olympia	NP 80-24	LQ
AEG Olympia	NP 80-24E	LQ
AEG Olympia	NP 136 SE	FX
AEG Olympia	NP 136-24	LQ
AEG Olympia	NPC 136-24	LQ

Alps

Manufacturer	Model	Driver
-----	-----	-----
Alps	Allegro 24	LQ
Alps	Allegro 500	LQ
Alps	Allegro 500XT	LQ
Alps	ALQ 218	FX
Alps	ALQ 224	LQ
Alps	ALQ 224E	LQ
Alps	ALQ 224GX	LQ

Alps	ALQ 318	FX
Alps	ALQ 324	LQ
Alps	ALQ 324E	LQ
Alps	ALQ 324GX	LQ
Alps	ALQ 3001	FX
Alps	ASP 1000	FX
Alps	ASP 1600	FX
Alps	DMX 800	FX
Alps	LPX 2020	LJ II
Alps	LSX 1600	LJ II
Alps	P2000+	FX
Alps	P2100	FX
Alps	P2400 C	LQ
Alps	P2418	FX
Alps	P2424 C	LQ

Brother

Manufacturer	Model	Driver
-----	-----	-----
Brother	HJ-100i	BJ
Brother	HL-4	LJ II
Brother	HL-4V	LJ II
Brother	HL-4Ve	LJ II
Brother	HL-8e	LJ II
Brother	HL-8V	LJ II
Brother	HL-10V	LJ II
Brother	M-1109	FX
Brother	M-1209	FX
Brother	M-1309	FX
Brother	M-1324	LQ
Brother	M-1709	FX
Brother	M-1724L	LQ
Brother	M-1809	FX
Brother	M-1824L	LQ
Brother	M-1909	FX
Brother	M-1924L	LQ
Brother	M-2518	FX
Brother	M-2524L	LQ
Brother	M-4018	FX
Brother	M-4309	FX
Brother	Twinriter 5	FX
Brother	Twinriter 6	FX
Brother	XL-500	FX
Brother	XL-1500	LQ

C. Itoh/C-Tech

Manufacturer	Model	Driver
-----	-----	-----
C. Itoh/C-Tech	9500	FX

C. Itoh/C-Tech	9515	FX
C. Itoh/C-Tech	9715	LQ
C. Itoh/C-Tech	C-240	FX
C. Itoh/C-Tech	C-245	FX
C. Itoh/C-Tech	C-310	FX
C. Itoh/C-Tech	C-315	FX
C. Itoh/C-Tech	C-510	LQ
C. Itoh/C-Tech	C-515	LQ
C. Itoh/C-Tech	C-610	LQ
C. Itoh/C-Tech	C-610 +	LQ
C. Itoh/C-Tech	C-610C +	LQ
C. Itoh/C-Tech	C-645	FX
C. Itoh/C-Tech	C-715 A	LQ
C. Itoh/C-Tech	CI-4	LJ II
C. Itoh/C-Tech	CI-8	LJ II
C. Itoh/C-Tech	CI-8E	LJ II
C. Itoh/C-Tech	ProWriter C-240	FX
C. Itoh/C-Tech	ProWriter C-245	FX
C. Itoh/C-Tech	ProWriter C-310 CXP	FX
C. Itoh/C-Tech	ProWriter C-610II	LQ
C. Itoh/C-Tech	ProWriter C-615II	LQ

Canon

Manufacturer	Model	Driver
-----	-----	-----
Canon	BJ-5	BJ
Canon	BJ-10e	BJ
Canon	BJ-10ex	BJ
Canon	BJ-20	BJ
Canon	BJ-130e	BJ
Canon	BJ-200	BJ
Canon	BJ-230	BJ
Canon	BJ-300	BJ
Canon	BJ-330	BJ
Canon	BJC-800	LQ
Canon	BJC-820	LQ
Canon	LBP-4 sx	LJ II
Canon	LBP-8 sx	LJ II

Citizen

Manufacturer	Model	Driver
-----	-----	-----
Citizen	120D	FX
Citizen	120D+	FX
Citizen	180D	FX
Citizen	200GX	FX
Citizen	200GX Fifteen	FX
Citizen	224	LQ
Citizen	5200	FX

Citizen	5800	FX
Citizen	GSX-130	LQ
Citizen	GSX-140	LQ
Citizen	GSX-140 Plus	LQ
Citizen	GSX-145	LQ
Citizen	GSX-240	LQ
Citizen	HSP-500	FX
Citizen	HSP-550	FX
Citizen	MSP-40	FX
Citizen	MSP-55	FX
Citizen	Overture 110	FX
Citizen	PN-48	LQ
Citizen	ProDot 9	FX
Citizen	ProDot 9X	FX
Citizen	ProDot 24	LQ
Citizen	ProJet	DJ
Citizen	ProLaser	LJ II
Citizen	ProScript	LJ II
Citizen	Swift 9	FX
Citizen	Swift 9X	FX
Citizen	Swift 24E	LQ
Citizen	Swift 24X	LQ

Compaq

Manufacturer	Model	Driver
-----	-----	-----
Compaq	PageMarq 15	LJ II
Compaq	PageMarq 20	LJ II

Epson

Manufacturer	Model	Driver
-----	-----	-----
Epson	ActionLaser	LJ II
Epson	ActionLaser 1000	LJ II
Epson	ActionLaser 1500	LJ II
Epson	ActionLaser II	LJ II
Epson	ActionLaser Plus	LJ II
Epson	ActionPrinter A-2000	FX
Epson	ActionPrinter A-2500	FX
Epson	ActionPrinter A-3000	LQ
Epson	ActionPrinter A-3250	LQ
Epson	ActionPrinter A-4000	LQ
Epson	ActionPrinter A-4500	LQ
Epson	ActionPrinter A-5000	LQ
Epson	ActionPrinter A-5500	LQ
Epson	ActionPrinter T-1000	LQ
Epson	Apex 80	FX
Epson	DFX-5000	FX
Epson	DFX-8000	FX

Epson	EPL-4000	LJ II
Epson	EPL-5000	LJ II
Epson	EPL-5200	LJ II
Epson	EPL-6000	LJ II
Epson	EPL-7000	LJ II
Epson	EPL-8000	LJ II
Epson	EX-800	FX
Epson	EX-1000	FX
Epson	FX-80	FX
Epson	FX-80 +	FX
Epson	FX-85	FX
Epson	FX-86e	FX
Epson	FX-100	FX
Epson	FX-100 +	FX
Epson	FX-185	FX
Epson	FX-286	FX
Epson	FX-286e	FX
Epson	FX-850	FX
Epson	FX-870	FX
Epson	FX-1050	FX
Epson	FX-1170	FX
Epson	HS-80	FX
Epson	JX-80	FX
Epson	L-750	LQ
Epson	L-1000	LQ
Epson	LQ-200	LQ
Epson	LQ-500	LQ
Epson	LQ-510	LQ
Epson	LQ-570	LQ
Epson	LQ-800	LQ
Epson	LQ-850	LQ
Epson	LQ-860	LQ
Epson	LQ-870	LQ
Epson	LQ-950	LQ
Epson	LQ-1000	LQ
Epson	LQ-1010	LQ
Epson	LQ-1050	LQ
Epson	LQ-1060	LQ
Epson	LQ-1070	LQ
Epson	LQ-1170	LQ
Epson	LQ-1500	LQ
Epson	LQ-2500	LQ
Epson	LQ-2550	LQ
Epson	LX-80	FX
Epson	LX-86	FX
Epson	LX-90	FX
Epson	LX-800	FX
Epson	LX-810	FX
Epson	SQ-850	LQ
Epson	SQ-2000	LQ
Epson	SQ-2500	LQ
Epson	SQ-2550	LQ
Epson	Stylus-800	LQ

Epson	T-750	FX
Epson	T-1000	FX

Fujitsu

Manufacturer	Model	Driver
-----	-----	-----
Fujitsu	Breeze 100	DJ
Fujitsu	Breeze 200	DJ
Fujitsu	DL 1100	LQ
Fujitsu	DL 1100C	LQ
Fujitsu	DL 1150	LQ
Fujitsu	DL 1200	LQ
Fujitsu	DL 1200C	LQ
Fujitsu	DL 1250	LQ
Fujitsu	DL 2400	FX
Fujitsu	DL 2400C	FX
Fujitsu	DL 2600	FX
Fujitsu	DL 2600C	FX
Fujitsu	DL 3300	FX
Fujitsu	DL 3450	FX
Fujitsu	DL 3400	FX
Fujitsu	DL 3400C	FX
Fujitsu	DL 3600	LQ
Fujitsu	DL 3600C	LQ
Fujitsu	DL 4400	LQ
Fujitsu	DL 4400C	LQ
Fujitsu	DL 4600	LQ
Fujitsu	DL 4600C	LQ
Fujitsu	DL 5600	FX
Fujitsu	DL 5600C	FX
Fujitsu	DL 5800	LQ
Fujitsu	DL 5800C	LQ
Fujitsu	DX 2300	FX
Fujitsu	DX 2400	FX
Fujitsu	Print Partner 10	LJ II
Fujitsu	VM 2200	LJ II

Hewlett Packard

Manufacturer	Model	Driver
-----	-----	-----
Hewlett Packard	DeskJet	DJ
Hewlett Packard	DeskJet Plus	DJ
Hewlett Packard	DeskJet 500	DJ
Hewlett Packard	DeskJet 500C	DJ
Hewlett Packard	DeskJet 550C	DJ
Hewlett Packard	DeskJet Portable	DJ
Hewlett Packard	LaserJet 4	LJ II
Hewlett Packard	LaserJet II	LJ II
Hewlett Packard	LaserJet IID	LJ II

Hewlett Packard	LaserJet IIP	LJ II
Hewlett Packard	LaserJet IIP Plus	LJ II
Hewlett Packard	LaserJet III	LJ II
Hewlett Packard	LaserJet IIID	LJ II
Hewlett Packard	LaserJet IIIP	LJ II
Hewlett Packard	LaserJet IIISi	LJ II
Hewlett Packard	PaintJet XL300	LJ II
Hewlett Packard	RuggedWriter	LQ
Hewlett Packard	RuggedWriter 480	LQ

IBM/Lexmark

Manufacturer	Model	Driver
-----	-----	-----
IBM/Lexmark	2380 PPS II	FX
IBM/Lexmark	2381 PPS II	FX
IBM/Lexmark	2390	LQ
IBM/Lexmark	2390 PPS II	FX
IBM/Lexmark	2391 PPS II	FX
IBM/Lexmark	4019 LaserPrinter	LJ II
IBM/Lexmark	4019 LaserPrinter E	LJ II
IBM/Lexmark	4029-10 LaserPrinter SE	LJ II
IBM/Lexmark	4029-20 LaserPrinter 6	LJ II
IBM/Lexmark	4029-22 LaserPrinter 6P	LJ II
IBM/Lexmark	4029-30 LaserPrinter 10	LJ II
IBM/Lexmark	4029-40 LaserPrinter 10L	LJ II
IBM/Lexmark	4029-42 LaserPrinter 10P	LJ II
IBM/Lexmark	4070	BJ
IBM/Lexmark	4070 Execjet	LQ
IBM/Lexmark	4079	LQ
IBM/Lexmark	4226-302	FX
IBM/Lexmark	PS/1 printer	BJ

Kodak

Manufacturer	Model	Driver
-----	-----	-----
Kodak	Diconix 180si	FX
Kodak	Diconix 300	FX
Kodak	Diconix 300W	FX
Kodak	Diconix 701	DJ

Kyocera

Manufacturer	Model	Driver
-----	-----	-----
Kyocera	F-800	LJ II
Kyocera	F-800A	LJ II
Kyocera	F-820	LJ II
Kyocera	F-850	LJ II

Kyocera	F-1500A	LJ II
Kyocera	F-1800A	LJ II
Kyocera	F-2000A	LJ II
Kyocera	F-2010	LJ II
Kyocera	F-3000A	LJ II
Kyocera	F-3010	LJ II
Kyocera	F-3500A	LJ II
Kyocera	F-5000A	LJ II
Kyocera	F-5500A	LJ II
Kyocera	FS-1500A	LJ II

Support Information Services

Copyright 1994-95, Apple Computer, Inc.

Tech Info Library Article Number:14474