

Performa Basics: Can't Access Quit Button (4/94)

Revised: Security:	4/6/94 Everyone
Performa Basics	s: Can't Access Quit Button (4/94)
=========	
Article Created: 6 April 1994	
TOPIC	
When running Pe	erforma Basics, I am unable to access the Ouit button, or

When running Performa Basics, I am unable to access the Quit button, or the guidance buttons. There is about an inch at the top of the program that has nothing in it.

DISCUSSION -----

You probably have 640×400 video mode turned on in your Monitor Control Panel. Open your Monitor Control Panel, and reset the monitor back to "Macintosh High Resolution" and restart. That will return your system to 640×480 , and Performa Basics should run fine.

Support Information Services

Copyright 1994, Apple Computer, Inc

Tech Info Library Article Number: 15059