



Tech Info Library

Power Macintosh: Printing Fax In Landscape Orientation (6/94)

Revised: 6/20/94
Security: Everyone

Power Macintosh: Printing Fax In Landscape Orientation (6/94)

=====
Article Created: 20 June 1994

TOPIC -----

I am using a Power Macintosh with a GeoPort Telecom Adapter and the Express Modem software. I can both send and receive faxes, but I am unable print a fax from Fax Viewer in landscape mode. I have tried printing to several different printers including a LaserWriter Pro 630 and LaserWriter 810. I have changed the page setup dialog to show landscape printing but the fax prints out rotated ninety degrees with the bottom cut-off.

DISCUSSION -----

In order to print a received fax from Fax Viewer in a landscape orientation you must perform the following steps:

- 1) Open the fax you wish to print with the Fax Viewer application.
- 2) Choose "Page Setup" in the File menu and select Landscape orientation.
- 3) Choose Rotate Right (Cmd-r) or Rotate Left (Cmd-l) from the Page menu.
Note: If you have a multiple page fax then this must be done for each page you wish to print in landscape orientation.
- 4) Choose "Print" from the File menu to print the document.

Support Information Services

Copyright 1994, Apple Computer, Inc

Tech Info Library Article Number:15651