



Tech Info Library

QuickTake 100: LCD Panel Showing ER (6/94)

Revised: 6/23/94
Security: Everyone

QuickTake 100: LCD Panel Showing "ER" (6/94)

=====

Article Created: 23 June 1994

TOPIC -----

The Quicktake 100 camera I am using is showing the letters 'ER' on the LCD panel. What does this mean?

DISCUSSION -----

This is an error state. Check that you are using the appropriate power adaptor and it is properly connected to the camera. Turn the camera off and back on. If the LCD still reads ER, have the camera serviced by an authorized Apple service provider.

Support Information Services

Copyright 1994, Apple Computer, Inc

Tech Info Library Article Number:15681