



Tech Info Library

Newton Print Pack: Compatible Printers (M-X) (3/95)

Revised: 3/30/95
Security: Everyone

Newton Print Pack: Compatible Printers (M-X) (3/95)

=====
Article Created: 1 August 1994
Article Reviewed/Updated: 30 March 1995

TOPIC -----

Listed below are printers that will print to a Newton MessagePad when used with the Newton Print Pack.

DISCUSSION -----

Mannesman Tally

Manufacturer	Model	Driver
-----	-----	-----
Mannesman Tally	MT 150/9	FX
Mannesman Tally	MT 150/24	LQ
Mannesman Tally	MT 151/9	FX
Mannesman Tally	MT 151/24	LQ
Mannesman Tally	MT 81	FX
Mannesman Tally	MT 82	LQ
Mannesman Tally	MT 85	FX
Mannesman Tally	MT 86	FX
Mannesman Tally	MT 87	FX
Mannesman Tally	MT 88	FX
Mannesman Tally	MT 92C	DJ
Mannesman Tally	MT 130/9	FX
Mannesman Tally	MT 130/24	LQ
Mannesman Tally	MT 131/9	FX
Mannesman Tally	MT 131/24	LQ
Mannesman Tally	MT 222	LQ
Mannesman Tally	MT 230/9	FX
Mannesman Tally	MT 230/24	LQ
Mannesman Tally	MT 290	FX
Mannesman Tally	MT 330	LQ
Mannesman Tally	MT 340	FX
Mannesman Tally	MT 490	FX

Mannesman Tally	MT 645	FX
Mannesman Tally	MT 661	FX
Mannesman Tally	MT 691	FX
Mannesman Tally	MT 735	LJ II
Mannesman Tally	MT 904	LJ II
Mannesman Tally	MT 905	LJ II
Mannesman Tally	MT 906	LJ II
Mannesman Tally	MT 906WP	LJ II
Mannesman Tally	MT 908	LJ II
Mannesman Tally	MT 911	LJ II
Mannesman Tally	MT 911PS	LJ II
Mannesman Tally	MT 7400C	DJ

NEC

Manufacturer	Model	Driver
-----	-----	-----
NEC	P5XL	LQ
NEC	P6	LQ
NEC	P7	LQ
NEC	P9	LQ
NEC	P20	LQ
NEC	P30	LQ
NEC	P60	LQ
NEC	P70	LQ
NEC	P90	LQ
NEC	P2200	LQ
NEC	P2200XE	LQ
NEC	P3200	LQ
NEC	P3300	LQ
NEC	P5200	LQ
NEC	P5300	LQ
NEC	P6200	LQ
NEC	P6300	LQ
NEC	P8300	LQ
NEC	P9300	LQ
NEC	Silentwriter LC 260	LJ II
NEC	Silentwriter LC 860	LJ II

Okidata

Manufacturer	Model	Driver
-----	-----	-----
Okidata	DOC•IT 3000	LJ II
Okidata	DOC•IT 4000	LJ II
Okidata	LaserLine 6	LJ II
Okidata	MicroLine 184 Turbo	FX
Okidata	MicroLine 280	FX
Okidata	MicroLine 320	FX
Okidata	MicroLine 320 Elite	FX
Okidata	MicroLine 321	FX

Okidata	MicroLine 321 Elite	FX
Okidata	MicroLine 380	LQ
Okidata	MicroLine 390	LQ
Okidata	MicroLine 390 Elite	LQ
Okidata	MicroLine 390 FB	LQ
Okidata	MicroLine 390 Plus	LQ
Okidata	MicroLine 391	LQ
Okidata	MicroLine 391 Elite	LQ
Okidata	MicroLine 391 Plus	LQ
Okidata	MicroLine 393	LQ
Okidata	MicroLine 393 B Plus	LQ
Okidata	MicroLine 393 C	LQ
Okidata	MicroLine 393 C Elite	LQ
Okidata	MicroLine 393 C Plus	LQ
Okidata	MicroLine 393 Elite	LQ
Okidata	MicroLine 393 Plus	LQ
Okidata	MicroLine 520	FX
Okidata	MicroLine 521	FX
Okidata	MicroLine 590	LQ
Okidata	MicroLine 591	LQ
Okidata	MicroLine 3410	FX
Okidata	OkiLaser 400	LJ II
Okidata	OkiLaser 800	LJ II
Okidata	OkiLaser 810	LJ II
Okidata	OkiLaser 820	LJ II
Okidata	OkiLaser 830	LJ II
Okidata	OkiMate 240	LQ
Okidata	PaceMark 3410	FX

Panasonic

Manufacturer	Model	Driver
-----	-----	-----
Panasonic	KX-P1010	FX
Panasonic	KX-P1080	FX
Panasonic	KX-P1080i	FX
Panasonic	KX-P1090	FX
Panasonic	KX-P1091	FX
Panasonic	KX-P1091i	FX
Panasonic	KX-P1092	FX
Panasonic	KX-P1092i	FX
Panasonic	KX-P1093	FX
Panasonic	KX-P1123	LQ
Panasonic	KX-P1124	LQ
Panasonic	KX-P1124i	LQ
Panasonic	KX-P1160	FX
Panasonic	KX-P1180	FX
Panasonic	KX-P1180i	FX
Panasonic	KX-P1191	FX
Panasonic	KX-P1524	LQ
Panasonic	KX-P1592	FX
Panasonic	KX-P1595	FX

Panasonic	KX-P1624	LQ
Panasonic	KX-P1654	LQ
Panasonic	KX-P1695	FX
Panasonic	KX-P2023	LQ
Panasonic	KX-P2123	LQ
Panasonic	KX-P2124	LQ
Panasonic	KX-P2180	FX
Panasonic	KX-P2624	LQ
Panasonic	KX-P3123	LQ
Panasonic	KX-P3124	LQ
Panasonic	KX-P4410	LQ
Panasonic	KX-P4420	LJ II
Panasonic	KX-P4430	LJ II
Panasonic	KX-P4450i	LJ II
Panasonic	KX-P4451	LJ II

Roland

Manufacturer	Model	Driver
-----	-----	-----
Roland	LP-800	DJ II
Roland	PR-1212A	FX
Roland	PR-1515	LQ
Roland	PR-2416	LQ
Roland	PR-2417	LQ
Roland	PR-2465	LQ
Roland	PR-9101	FX
Roland	PR-9104	FX
Roland	PR-9606	FX

Seikosha

Manufacturer	Model	Driver
-----	-----	-----
Seikosha	BP-5420 FA	FX
Seikosha	BP-5460	FX
Seikosha	BP-5780	FX
Seikosha	LT-20	LQ
Seikosha	MP-1200 AI	FX
Seikosha	MP-1350 AI	FX
Seikosha	MP-3000 AI	FX
Seikosha	MP-3005 AI	FX
Seikosha	MP-5300 AI	FX
Seikosha	MP-5305 AI	FX
Seikosha	MP-5350 AI	FX
Seikosha	OP-104	LJ II
Seikosha	OP-108	LJ II
Seikosha	OP-115	LJ II
Seikosha	OP-215	LJ II
Seikosha	Priente 900	FX
Seikosha	Priente 2400	LQ

Seikosha	SBP-10 AI	FX
Seikosha	SBP-10 CX	FX
Seikosha	SBP-10 Plus	FX
Seikosha	SBP-10 TX	FX
Seikosha	SK-3000 AI	FX
Seikosha	SK-3005 AI	FX
Seikosha	SK-3005 Plus	FX
Seikosha	SL-80 AI	LQ
Seikosha	SL-90	LQ
Seikosha	SL-90 AI	LQ
Seikosha	SL-90 Plus	LQ
Seikosha	SL-92 Plus	LQ
Seikosha	SL-130 AI	LQ
Seikosha	SL-210	LQ
Seikosha	SL-230 AI	LQ
Seikosha	SL-270	LQ
Seikosha	SL-532	LQ
Seikosha	SP-10 Plus	FX
Seikosha	SP-185 AI	FX
Seikosha	SP-1600 AI	FX
Seikosha	SP-1900 Plus	FX
Seikosha	SP-2000 AI	FX
Seikosha	SP-2000 Plus	FX
Seikosha	SP-2000 S	FX
Seikosha	SP-2400	FX
Seikosha	SP-2415	FX

Sharp Electronics

Manufacturer	Model	Driver
-----	-----	-----
Sharp Electronics	JX-9500	LJ II
Sharp Electronics	JX-9500H	LJ II
Sharp Electronics	JX-9500PS	LJ II
Sharp Electronics	JX-9550	LJ II
Sharp Electronics	JX-96500	LJ II
Sharp Electronics	JX-9700	LJ II

Star Micronics

Manufacturer	Model	Driver
-----	-----	-----
Star Micronics	LaserPrinter 4	LJ II
Star Micronics	LaserPrinter 8II	LJ II
Star Micronics	LC 10	FX
Star Micronics	LC 20	FX
Star Micronics	LC 24-15	LQ
Star Micronics	LC 24-20	LQ
Star Micronics	LC 24-200	LQ
Star Micronics	LC 24-200 Colour	LQ
Star Micronics	LC 200	FX

Star Micronics	NB 15	LQ
Star Micronics	NB 24-10	LQ
Star Micronics	NB 24-15	LQ
Star Micronics	NX 15	FX
Star Micronics	NX 1000	LQ
Star Micronics	NX 1000 II	FX
Star Micronics	NX 1000 Rainbow	FX
Star Micronics	NX 1001	FX
Star Micronics	NX 1020 Rainbow	FX
Star Micronics	NX 1500	FX
Star Micronics	NX 2400	LQ
Star Micronics	NX 2410	LQ
Star Micronics	NX 2415	LQ
Star Micronics	NX 2420 Rainbow	LQ
Star Micronics	NX 2430	LQ
Star Micronics	StarJet SJ-48	LQ
Star Micronics	XB 2410	LQ
Star Micronics	XB 2415	LQ
Star Micronics	XB 2420	LQ
Star Micronics	XB 2425	LQ
Star Micronics	XR 1000	FX
Star Micronics	XR 1020	FX
Star Micronics	XR 1500	FX
Star Micronics	XR 1520	FX

Tandy/Radio Shack

Manufacturer	Model	Driver
-----	-----	-----
Tandy/Radio Shack	DMP 103	FX
Tandy/Radio Shack	DMP 135	FX
Tandy/Radio Shack	DMP 136	LQ
Tandy/Radio Shack	DMP 240	LQ
Tandy/Radio Shack	DMP 302	LQ
Tandy/Radio Shack	DMP 2103	LQ
Tandy/Radio Shack	DMP 2104	LQ
Tandy/Radio Shack	DMP 2130	LQ
Tandy/Radio Shack	LP 950	LJ II
Tandy/Radio Shack	LP 990	LJ II

Texas Instruments

Manufacturer	Model	Driver
-----	-----	-----
Texas Instruments	875	LQ
Texas Instruments	877	LQ
Texas Instruments	8920	FX
Texas Instruments	8930	FX
Texas Instruments	microLaser	LJ II
Texas Instruments	microLaser Plus	LJ II
Texas Instruments	microLaser Plus PS17	LJ II

Texas Instruments	microLaser Plus PS35	LJ II
Texas Instruments	microLaser PS	LJ II
Texas Instruments	microLaser PS17	LJ II
Texas Instruments	microLaser Turbo	LJ II
Texas Instruments	microLaser XL	LJ II
Texas Instruments	microLaser XL PS17	LJ II
Texas Instruments	microLaser XL PS35	LJ II
Texas Instruments	microLaser XL Turbo	LJ II

Toshiba

Manufacturer	Model	Driver
-----	-----	-----
Toshiba	ExpressWriter 201	LQ
Toshiba	ExpressWriter 420	LQ
Toshiba	ExpressWriter 440	LQ
Toshiba	GX200	LJ II
Toshiba	GX400	LJ II
Toshiba	PageLaser 6	LJ II
Toshiba	PageLaser 12	LJ II

Xerox

Manufacturer	Model	Driver
-----	-----	-----
Xerox	4197 MICR	LJ II
Xerox	4213	LJ II
Xerox	4235	LJ

Support Information Services

Copyright 1994-95, Apple Computer, Inc.

Tech Info Library Article Number:15969