

Apple MessagePad 110: System 1.3 Update Read Me (2/95)

Information about a modem-related problem with the MessagePad 110 and System Update 1.3 (345025):

When you have used a modem to initiate a telephone call to someone and you click the close box on the MessagePad 110 to tell the modem that it can hang up (because you have lifted the telephone receiver to begin talking with the person), the modem does not hang up and the buttons on the bottom of your MessagePad screen don't respond to taps.

To be able to use the buttons on your MessagePad screen again, press the Reset button inside the battery compartment on the MessagePad. (Pressing Reset does not erase the information in your MessagePad.)

If you used an Apple external modem to initiate the call, you also need to remove and then reinsert one of the batteries in the modem to hang up the modem (to stop the modem from depleting its battery power).

Note: This problem does not occur when you use the modem for other purposes, such as faxing or NewtonMail.

Support Information Services

Copyright 1995, Apple Computer, Inc

Tech Info Library Article Number:17145