



Tech Info Library

Pointer Mode Control Panel: ReadMe File (11/95)

Revised: 11/22/95
Security: Everyone

Pointer Mode Control Panel: ReadMe File (11/95)

=====
Article Created: 04 August 1995
Article Reviewed/Updated: 22 November 1995

TOPIC -----

This article contains the Read Me file for the Pointer Mode control panel that ships with System 7.5.2 on Power Macintosh 7200 computers.

DISCUSSION -----

Including the Pointer in Screen Captures

If you take a screen shot and the pointer does not appear in the captured graphic, you can use the Pointer Mode control panel to ensure that the screen-capture program includes the pointer.

To install the Pointer Mode control panel, follow these steps:

1. Drag the Pointer Mode control panel icon to the System Folder icon on your hard disk (do not open the System Folder).
2. When a message appears asking if you want the control panel placed in the Control Panels folder, click OK. Your computer recognizes that this is a control panel and automatically places it in the Control Panels folder.

To use the Pointer Mode control panel:

1. Open the Apple menu and choose Control Panels.
2. Double-click the Pointer Mode control panel to open it.
3. Click the checkbox to set the pointer to standard mode.

If you find that the pointer flashes a lot when you place it over graphics, you may want to use the Pointer Mode control panel to turn off standard mode.

Article Change History:

22 Nov 1995 - Updated title

20 Nov 1995 - Reviewed for technical accuracy.

Support Information Services

Copyright 1995, Apple Computer, Inc.

Tech Info Library Article Number:18315