



Tech Info Library

No Shell Command to Eject CD-ROM Discs (9/95)

Revised: 9/14/95
Security: Everyone

No Shell Command to Eject CD-ROM Discs (9/95)

=====
Article Created: 13 September 1995

TOPIC -----

Can I use a UNIX line command to eject a CD-ROM disc?

DISCUSSION -----

There is no shell command that will eject a CD-ROM disc under A/UX. The only way to eject a CD-ROM disc under A/UX is by dragging its icon to the Trash.

Support Information Services

Copyright 1995, Apple Computer, Inc.

Tech Info Library Article Number:18563