



# Tech Info Library

## Network Server: How To Eject A Floppy Disk (10/96)

Revised: 10/29/96  
Security: Everyone

Network Server: How To Eject A Floppy Disk (10/96)

=====  
Article Created: 29 October 1996

TOPIC -----

On my RS6000, I have an eject button for the floppy drive. On the Apple Network Server, there is no eject button. How do I get the floppy disk out?

DISCUSSION -----

Open a terminal window (if you are in CDE) and type the command "fdeject" to eject the floppy disk.

Copyright 1996, Apple Computer, Inc.

Tech Info Library Article Number:20594