



Tech Info Library

PowerBook 1400:Target Disk Mode & Internal CD drive (4/97)

Revised: 4/9/97
Security: Everyone

PowerBook 1400:Target Disk Mode & Internal CD drive (4/97)

=====
Article Created: 09 April 1997

TOPIC -----

The media bay CD-ROM drive for the PowerBook 1400 does not mount when the PowerBook is placed in Target Disk Mode. Is there something wrong?

DISCUSSION -----

There is nothing wrong with the computer. The media bay CD-ROM drive does not support Target Disk Mode. An external CD-ROM drive can be used in the SCSI chain with the appropriate termination.

For more information on SCSI/Target Disk Mode, please see the following Tech Info Library articles:

- "PowerBook: Miscellaneous Frequently Asked Questions"
- "PowerBook: Which Models Support SCSI Disk Mode"
- "PowerBook: SCSI Disk Mode and Termination"

Copyright 1997, Apple Computer, Inc.

Tech Info Library Article Number:21148