



# Tech Info Library

## PowerBook: How to Clean the Trackball (7/96)

Revised: 7/1/96  
Security: Everyone

PowerBook: How to Clean the Trackball (7/96)

=====

Article Created: 13 November 1991  
Article Reviewed/Updated: 01 July 1996

TOPIC -----

My PowerBook's trackball doesn't work smoothly; it appears to "stick" or "jump" when rolled.

DISCUSSION -----

Most PowerBook trackball problems are due to contamination of the rollers. The trackball is just like the standard Apple mouse in that dust and debris can accumulate on the rollers and impede smooth movement of the trackball.

### Symptoms of a Dirty Trackball

=====

Symptoms that your trackball is dirty are:

- The trackball appears to "stick" or "jump" when rolled.
- The cursor will not track horizontally or vertically.
- It sometimes seems like the cursor is "hitting a wall".
- On-screen buttons fail to activate when you click on them.
- The movement of the cursor on the screen isn't smooth.
- The trackball is physically difficult to roll.

### How to Clean the Trackball

=====

- 1) Remove the trackball retaining ring by turning it counterclockwise until it pops out (about 1/4 turn). You don't need tools for this; you can just press against the two small ridges on the ring with your fingernails.
- 2) Lift the retaining ring and trackball out of its cavity.

- 3) Locate the small rubber rollers at the left and bottom sides of the trackball cavity. Depending on your model, they may look like small rings or wheels.
- 4) Use any reasonably clean, blunt object (such as your finger or a cotton swab) to wipe off the rollers. Do not use any liquid, including any amount of cleaning fluid or water, inside the computer.
- 5) Locate the three white or red bearings located at approximately clockwise 4:00, 7:00, and 11:00 in all PowerBooks except the PowerBook 100, which has three black posts instead of bearings. Using a fingertip, dry cotton swab, or other blunt object, clean them of any debris.
- 6) Replace the trackball and the retaining ring.

In addition, on a PowerBook 140 or 170, reseating the cables on the trackball and keyboard may solve the problem. This is very effective if the failure is related to the computer heating up. These cables are located inside the PowerBook, so your authorized service provider or Apple must do this.

This article is one of many available through the Apple Fax center. For a complete list of available fax documents, search the Tech Info Library for Apple Fax Document Index or call the Apple Fax line at 1-800-505-0171 and select document number 20000 (Apple Fax - Document Index - Product Support Literature).

The Apple Fax center is available free of charge 24 hours a day, 7 days a week.

#### Article Change History:

- 01 Jul 1996 - Added Fax Doc Word
- 12 Oct 1994 - Added keyword; added note about PB 140 and 170.
- 28 Sep 1994 - Reviewed for technical accuracy.
- 30 Jun 1994 - Revised clock position of first roller from 3:00 to 4:00.
- 22 Jun 1994 - Combined with similar article, additional symptoms added.

Support Information Services

Copyright 1991-96, Apple Computer, Inc.

Tech Info Library Article Number:9300