



# Tech Info Library

## LaserWriter Plus: Additional Error Codes

Revised: 8/2/88  
Security: Everyone

LaserWriter Plus: Additional Error Codes

=====

This article last reviewed: 19 July 1988

BEFORE YOU START: Familiarize yourself with the LaserWriter Plus Technical Procedures, especially the section on the built-in diagnostics. Be sure to follow proper ESD procedures when replacing ROMs.

When using the built-in diagnostics of a LaserWriter Plus to test the ROMs on the I/O board sometimes an error code will occur that the instructions on error codes in the LaserWriter Technical Procedures do not help with. In all cases, only the last 2 digits of the error code are of concern.

If the error code was 024B 1E08, the H3 ROM and/or L3 ROM would be bad, or if the error code was 024B 1E80 the H7 ROM and/or L7 ROM would be bad, as indicated by the LaserWriter Plus Technical Procedures.

Now, suppose that the error code received is 024B 1E0A, since only the last 2 numbers have any meaning, we are only concerned with the "0A" at the end of the number. Decoding this error code becomes more difficult because error codes are added together if more than 1 ROM set is detected by the built-in diagnostics as bad. The addition is of 2 hexadecimal numbers so adding 08 and 02 in hexadecimal gives 0A and the corresponding error code 024B 1E0A. This indicates that there are possibly 4 bad ROMs instead of 2. In this example, the possible bad ROMs are either H3 or L3 and H1 or L1. This was determined by checking which of the error codes would add up to "0A" in hexadecimal.

Below is a list of other possible error codes that might occur. This list only gives those that would indicate 2 or more sets of bad ROMs. Be sure to refer to the LaserWriter Technical Procedures for more information on running and diagnosing the failures. If the error codes indicate several bad ROMs, the failure may be in the I/O board itself. In this event, exchange the I/O board.

ERROR CODE                      POSSIBLE BAD ROMs

Lower Bank

XXXX XX03	H1, L1, H0, L0
XXXX XX05	H2, L2, H0, L0
XXXX XX06	H2, L2, H1, L1
XXXX XX07	H2, L2, H1, L1, H0, L0
XXXX XX09	H3, L3, H0, L0
XXXX XX0A	H3, L3, H1, L1
XXXX XX0B	H3, L3, H2, L2, H0, L0
XXXX XX0C	H3, L3, H2, L2
XXXX XX0D	H3, L3, H2, L2, H0, L0
XXXX XX0E	H3, L3, H2, L2, H1, L1
XXXX XX0F	All 8 LOWER ROMs

Upper Bank

XXXX XX03	H5, L5, H4, L4
XXXX XX50	H6, L6, H4, L4
XXXX XX60	H6, L6, H5, L5
XXXX XX70	H6, L6, H5, L5, H4, L4
XXXX XX90	H7, L7, H4, L4
XXXX XXA0	H7, L7, H5, L5
XXXX XXB0	H7, L7, H6, L6, H4, L4
XXXX XXC0	H7, L7, H6, L6
XXXX XXD0	H7, L7, H6, L6, H4, L4
XXXX XXE0	H7, L7, H6, L6, H5, L5
XXXX XXF0	All 8 UPPER ROMs

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:3115