

Super Serial Card: Using with Machine Language (12/96)

Revised: 12/16/96 Security: Everyone

Super Serial Card: Using with Machine Language (12/96)

Article Created: 22 September 89 Article Reviewed/Updated: 16 December 1996

TOPIC -----

This article describes assembly language addressing methods for the 6502 and 6551 microprocessors through the Super Serial Card.

DISCUSSION -----

The 6502 does a false read to the current page. This is inherent in the 6502 design. A false read occurs during a read to memory. The 6502 will hold the target address + 1 line open after it accesses the target address. This does not alter the contents of the address but can affect a memory-mapped I/O device that is toggled by the address line.

The false read does not affect the Super Serial Card as none of the card's functions are set when the address line is held open by the false read. However, for good programming to an I/O device, where false reads could toggle a function, you should use the indirect indexed-addressing mode with the address for your indirect accesses in the zero page.

The following example is available in the Tech Info Library and uses the absolute, indirect-addressing method; it has been modified here as an example of indirect, indexed-addressing. The program uses zero-page addresses \$FA and \$FB, because these are generally unused by both DOS and BASIC. See pages 74 and 75 of the "Apple II Reference Manual" for a map of the zero-page locations.

Super Serial Card: Accessing It Through Machine Language

Although Apple's Super Serial Card can be used from Applesoft BASIC, it is often desirable to use machine language to increase the speed with which characters are sent and received. The assembler program below illustrates a method of communicating with another computer through the Super Serial Card. You may use this routine as a starting point for your own program.

..TIL04435-Super_Serial_Card-Using_with_Machine_Language_12-96_(TA40372).pdf

On page 291 of the "Apple IIe Reference Manual" and on pages 261 to 265 of the Apple IIc Reference Manual, there are lists of the registers and entry points used by routines resident in the Super Serial Card. The equates in the program below use these locations, as well as input/output hooks found in the Apple II family of computers.

The initialization routine (INIT) stores the address of the Super Serial Card's initialization routine in CSW (the Apple II monitor character output hook). This activates the card for output by jumping to COUT. Following this, DOS or ProDOS hooks are reinstalled.

The OUTput routine checks the 6551 status port bit 4. If this is equal to zero, the previous character has not yet been sent, so we must check the status byte again until that register is clear. When the value in bit 4 becomes one, the 6551 is ready to send another character. To do this, store the data in the transmit register (TDREG) of the chip.

Bit 3 of the status port is checked by the INput routine. If this bit is zero, the program either loops continuously or returns to the calling program, depending on the state of the return flag found in location \$FF. If bit 3 is one, a character is waiting at the input port, and the character is then read from the read register (RDREG) of the 6551.

The DEMO portion of this program calls the INIT routine, and sends each letter of the alphabet to the connected device. After each character is sent, the program waits to see if a response has been received from the external device. If a character is waiting, the program ends.

Assembly Language Source Code Demo

Here is a demo of accessing the Super Serial Card with Assembly Language.

	ORG	\$2000	
COUT	EQU	\$FDED	; CHARACTER OUT IN MONITOR
CSWL	EQU	\$36	; OUTPUT HOOK
CSWH	EQU	\$37	
WAIT	EQU	\$FCA8	; MONITOR ROUTINE TO WAIT
BASELO	EQU	\$FA	; ZERO PAGE INDEX ADDRESS FOR INDIRECT ADDRESSING
BASEHI	EQU	\$FB	; THE TARGET ADDRESS IS STORED IN FA AND FB
IO	EQU	\$C0	; IO PAGE HIBYTE ADDRESS THIS GOES IN BASEHI
;			
; SSC EQ)UATES		
; SSC EQ ;)UATES		
-	OUATES		
-	QUATES EQU	\$81	; +N0 DIPSWITCH BLOCK 1
;	-	\$81 \$82	; +N0 DIPSWITCH BLOCK 1 ; +N0 DIPSWITCH BLOCK 2
; DIPSW1	EQU	•	
; DIPSW1 DIPSW2	EQU EQU	\$82	; +N0 DIPSWITCH BLOCK 2
; DIPSW1 DIPSW2 TDREG	EQU EQU EQU	\$82 \$88	; +N0 DIPSWITCH BLOCK 2 ; +N0 6551 DATA REGISTER

..TIL04435-Super_Serial_Card-Using_with_Machine_Language_12-96_(TA40372).pdf

COMMAND EOU \$8A ; +NO 6551 COMMAND REG CONTROL EQU \$8B ; +N0 6551 CONTROL REG ; ; SKIP AROUND ALL THE SUBROUTINES START JMP DEMO ; ; USE THE SSC FIRMWARE TO INITIALIZE THE 6551. ; INIT LDA CSWL ; STORE THE CURRENT CSW PHA ; SO THAT WE DO NOT DISCONNECT LDA CSWH ; DOS OR ProDOS PHA #\$00 ; STORE \$Cs00 IN CSW LDA STA CSWL STX CSWH ; THIS ALREADY CONTAINS \$Cs #\$00 LDA JSR COUT ; JUMP TO COUT TO INIT THE CARD PLA STA CSWH ; RESTORE THE DOS OR ProDOS PLA ; HOOKS AND THEN RETURN STA CSWL RTS ; ; OUTPUT A CHARACTER TO 6551 ; OUT ; STORE DATA ON STACK PHA LDA #STATUS ; GET THE STATUS ADDRESS STA ; SET UP THE INDIRECT INDEXED ACCESS BASELO (BASELO),Y ; CHECK BIT 4 OF STATUS BYTE OLP LDA ; TO SEE IF IT'S OK TO SEND AND #\$10 BEQ OLP ; CHARACTER WAITING TO GO OUT LDA #TDREG ; ADDRESS FOR TRANSMIT STA BASELO SET UP THE INDIRECT INDEXED ACCESS ; PLA ; GET DATA BACK FROM STACK (BASELO),Y ; AND OUTPUT THE CHARACTER STA RTS ; ; INPUT A CHARACTER FROM 6551 IN LDA #STATUS ; GET THE STATUS ADDRESS STA BASELO ; SET UP THE INDIRECT INDEXED ACCESS LDA (BASELO),Y ; CHECK STATUS #\$08 AND ; BIT 3 OF STATUS BEQ INTST ; NO CHAR WAITING TO BE RECEIVED #RDREG ; GET THE READ ADDRESS LDA STA ; SET UP THE INDIRECT INDEXED ACCESS BASELO LDA (BASELO), Y ; GET THE INPUT FROM 6551 RTS ; CHECK RETURN FLAG INTST LDA \$FF BNE IN ; IF NOT 0 THEN WAIT FOR INPUT RTS ; IF ZERO, DON'T WAIT ; BEGIN THE DEMO PROGRAM ;

..TIL04435-Super_Serial_Card-Using_with_Machine_Language_12-96_(TA40372).pdf

;				
DEMO	LDY #	‡\$10	;	Y CONTAINS \$s0 - DEMO USES SLOT 1
	LDX #	‡\$C1	;	LOAD X WITH \$Cs
	JSR I	INIT	;	INIT THE CARD
	LDA #	‡IO	;	HIBYTE ADDRESS CO FOR IO ACCESS
	STA E	BASEHI	;	STORE IT IN ZERO PAGE AS HIBYTE OF ADDRESS
	LDA #	‡\$FF	;	SET RETURN FLAG FOR INPUT
	STA \$	\$FF	;	FF MEANS WAIT FOR CHAR
	JSR I	EN	;	INPUT A CHARACTER - SEE ABOVE
OLOOP	LDX #	‡\$41	;	OUTPUT THE ASCII CODES
OLP1	TXA		;	FROM A-Z TO THE SSC. IT WILL STOP
	JSR C	TUC	;	WHEN THE SSC RECEIVES A CHAR.
	LDA #	‡\$80	;	DELAY BETWEEN CHARACTERS
	JSR W	TIAN	;	TO ALLOW TIME FOR INPUT.
	LDA #	‡\$00		
	STA \$	ŞFF	;	RETURN IF NO CHARS WAITING
	JSR I	EN	;	CHECK FOR A CHARACTER
	BNE A	ALLDONE	;	THEY SENT SOMETHING - WE END
	INX			
	CPX #	‡\$5B	;	THE LETTER 'Z'
	BNE C	DLP1		
	LDA #	‡\$0D		
	JSR C	TUC	;	SEND A CARRIAGE RETURN
	JMP C	DLOOP	;	BEGIN THE ALPHABET AGAIN
ALLDONE	RTS		;	END ROUTINE

Article Change History:

16 Dec 1996 - Reviewed for technical accuracy, revised formatting.

Copyright 1989-96, Apple Computer, Inc.

Tech Info Library Article Number:4435