



Tech Info Library

Display Card 8/24GC: Using with Sony Monitors

Revised: 7/16/90
Security: Everyone

Display Card 8/24GC: Using with Sony Monitors

=====

This article last reviewed: 29 May 1990

TOPIC -----

I want to use the Sony MultiScan CPD-1304 monitor with the new Display Card 8/24GC. Will this work?

DISCUSSION -----

If the CPD-1304 monitor works with the Macintosh High-Resolution Video Card (the current 8-bit display card), there won't be any problem with the Display Card 8/24GC signals driving the Sony CPD-1304. (We could not verify that the CPD-1304 monitor works with the Macintosh High-Resolution Video Card, but we do know that Sony's CPD-1302 monitor works with that card.) However, you will need to use a different cable to connect the two devices because the cards have different connectors.

An issue with regard to the cable concerns the sense pins, which tell the card what type of monitor is attached. For the Sony CPD-1302 monitor, the sense pins should be configured as below, where 0 = Ground and 1 = Not Ground. To ground a sense pin, tie it to the C&VSYNC.GND signal.

Sense pins	Hor x Vert	Dot	Vert
10 7 4	Display	Clock	Refresh
-----	-----	-----	-----
1 1 0	12" Monochrome Monitor 13" Color Monitor	30.24	66.7

Here are the pinouts for the Macintosh Display Card 8/24GC:

Pin	Signal	Description
-----	-----	-----
1	RED.GND	Red Video Ground
2	RED.VID	Red Video
3	CYSNC~	Composite Sync

4	MON.ID1	Monitor ID, Bit 1 (also known as SENSE0)
5	GRN.VID	Green Video
6	GRN.GND	Green Video Ground
7	MON.ID2	Monitor ID, Bit 2 (also known as SENSE1)
8	nc	(no connection)
9	BLU.VID	Blue Video
10	MON.ID3	Monitor ID, Bit 3 (also known as SENSE2)
11	C&VSYNC.GND	CSYNC & VSYNC Ground
12	VSYNC~	Vertical Sync
13	BLU.GND	Blue Video Ground
14	HSYNC.GND	HSYNC Ground
15	HSYNC~	Horizontal Sync
Shell	CHASSIS.GND	Chassis Ground

Copyright 1990 Apple Computer, Inc.

Tech Info Library Article Number:5645