Tech Info Library

Network Server: Status Panel Number Descriptions (5/96)

```
Revised:        5/21/96
Security:       Everyone


Network Server:  Status Panel Number Descriptions (5/96)


=======================================================================


Article Created: 21 May 1996


TOPIC -----------------------------------------------------------


This article lists the more common values on the front status panel of the
Network Server 500 and 700.


DISCUSSION ------------------------------------------------------


LCD   System Action
---   -------------
510   The system has started the configuration manager.
511   The configuration manager has completed.
517   The system is attempting to mount the / (root) and /usr file systems.
538   The configuration manager is passing control to a configuration method
539   The configuration method has completed.
551   The system is attempting to varyon the root volume group.
553   The system has completed phase one of the boot process.
591   The system is configuring the Logical Volume Manager (LVM).
593   The system is configuring the low-function graphics terminal.
594   The system is configuring the rendering context manager.
704   The system is configuring a SCSI disk drive.
723   The system is configuring a CD-ROM or other SCSI device.
727   The system is configuring an asynchronous device.
731   The system is configuring a pseudo TTY.
811   The system is configuring the system planar (motherboard).
812   The system is configuring the standard I/O adapter.
814   The system is configuring the NVRAM.
821   The system is configuring the standard keyboard adapter.
823   The system is configuring the standard mouse adapter.
826   The system is configuring on-serial port 1.
828   The system is configuring the standard floppy disk adapter.
831   The system is configuring serial port 2.
868   The system is configuring the integrated SCSI adapter.
874   The system is configuring the graphics subsystem adapter.
921   The system is configuring a  keyboard.
```

```
925  The system is configuring a  mouse.
935  The system is configuring a 3.5-inch diskette drive.
9002 The system is configuring a SCSI-2 adapter.
```

Tech Info Library Article Number:19831